



XAPP1217 (v1.0) March 17, 2015

# Zero Latency Multiplexing I/O for ASIC Emulation


Author: Luis Bielich

## Summary

This application note provides a method for FPGA emulation platforms to communicate multiple signals over one I/O or I/O differential pair to another FPGA. This multiplexing method serializes data up to 800 Mb/s without introducing any additional cycles of latency to the user who is running at a slower rate.


## Overview

FPGAs are commonly used for emulation systems of complex ASICs. Because the ASIC logic outnumbers the logic in an FPGA, multiple FPGAs are required and the ASIC logic is distributed between the multiple FPGAs. The communication between FPGAs is a result of the ASIC being subdivided, so it is possible for hundreds or even thousands of logical signals to be needed to cross from one FPGA to the next. Even with the largest FPGAs, there might not be enough general purpose I/O to send all of the signals from one FPGA to another. Serializing a parallel path from one FPGA to another is a common method to enable one I/O to account for multiple signals going from one FPGA to another. This method is called *Multiplexing I/O* in this application note. [Figure 1](#) shows the serialization concept.



**Figure 1: Multiplexing I/O Conceptual Block Diagram**

Although serializing appears as the obvious solution for getting multiple signals over one I/O, this application note focuses on getting all the signals over in less than one parallel clock cycle, as in zero latency. The benefit of getting all of the signals over in less than one clock cycle is that the ASIC logic does not need to be modified as long as there are no timing bottlenecks. To get all of the bits over in one clock cycle, the effective multiplexed ratio must be reduced. For example, if the serial bit time is 32x the parallel frequency, the effective multiplexing capability must be less than 32x. The reasoning behind the reduction in the effective multiplexed ratio is shown in [Figure 2](#), which displays how the first bits transmitted are received before the next parallel clock cycle, allowing for bits to be utilized by the design before the subsequent parallel clock edge. The bits showing up after the parallel clock are referred to as *clipped bits* in the context of this document, and they are the bits that are discarded. In [Figure 2](#), bits A[31:21] are considered clipped bits, while bits A[20:0] are the valid bits yielding the effective multiplexing ability of 21 to 1 for every I/O or I/O differential pair.



**Figure 2: Multiplexing I/O Conceptual Waveform**

As illustrated in [Figure 2](#), the digital latency, trace delay, package delay, and IDELAY delay subtract from the valid bits. The more total delay, the less valid bits available and the more bits are clipped. Therefore, minimizing these delays is always encouraged. Skew between the parallel clocks on both FPGAs also affects the effective valid bits. When possible, reduce the skew of the parallel clock domains.


## Hardware Description

There are two designs provided in this application note, each packaged as a piece of custom IP for the Vivado® Design Suite:

- Output MUX transmitter
- Input DeMUX receiver

### Transmitter


The transmitter polls the parallel clock waiting for a rising edge. After a rising edge is detected, the transmitter starts transmitting the user data at the serial rate with the ODDR primitive. In [Figure 2](#), the user data is referred to as the valid bits. The transmitter transmits the valid bits first and the clipped bits later. The clipped bits are assigned to zero. The number of valid bits transmitted is designated by the effective multiplexing ratio, which is designated by the DATA\_WIDTH parameter. The total number of bits transmitted in a parallel clock is designated by the FULL\_WIDTH parameter. The difference between the FULL\_WIDTH and the DATA\_WIDTH results in the clipped bits, as shown in [Figure 3](#).



*Figure 3: Transmit Multiplexer Block Diagram*

## Receiver

The receiver passes the data through an IDELAY primitive before getting captured with the IDDR primitive. After the IDDR, the valid bits are deserialized into the parallel domain while the clipped bits are discarded and never presented to the user. To determine which bits are valid or clipped, a calibration stage is needed upon the release of reset. [Figure 4](#) shows a block diagram of the receiver design.



*Figure 4: Receiver DeMUX Block Diagram*

## Calibration

The purpose of the calibration engine is to perform these two functions:


- Center the IDELAY taps to capture at the center of the valid eye
- Find the appropriate cycles where valid bits are located

The receiver must calibrate upon each power cycle, or after reset is released. Although the receiver is performing the calibration, the transmitter needs to be placed in calibration mode to provide the training pattern to the receiver. When the transmitter comes out of reset, it should be placed in a training mode where the user data is not passed in by keeping the stop\_training input deasserted. Instead, the training data from the training\_pattern input is transmitted.

**Note:** The training\_pattern should be kept as a static value, but is left as an input to accommodate for dynamic training patterns.

After the reset to the receiver is released, the receiver is in a calibration mode. The receiver comes out of calibration after the training pattern is detected. During receive calibration, the IDELAY taps are swept to find the center of the capture eye. After the center of the data valid window is found and the data matches the training pattern, the IDELAY taps are placed in the center of the capture eye and the calib\_comp signal asserts. The calib\_comp signal from the receiver should let the transmitter know that it is ready to come out of calibration. When multiple I/Os are used to multiplex I/Os, it is possible to leave all the transmitters in training


mode until all of the receivers have completed calibration. [Figure 5](#) shows the sequencing of the control and status signals for the transmitter and receiver.



*Figure 5: Control and Status Signal Sequencing*

## Partitioning the Design

You must decide where the ASIC logic is partitioned across FPGAs. It is recommended for these boundaries to have lower levels of logic to achieve timing closure. In [Figure 6](#), this refers to the blocks labeled User Logic. The User Logic code remains logically equivalent because it would be in the ASIC. The timing boundaries between the User Logic and the Serializer or Deserializer are tighter than the parallel clock period, which is why you should choose boundaries with lower levels of logic.



*Figure 6: Example of x16 User Data Width System*

# Hardware Requirements and Considerations

The list below provides the hardware requirements and considerations for using this application note:

- Parallel Clocks are System Synchronous and the Same Frequency
- Serial Clocks are System Synchronous and the Same Frequency
- Serial Clock and Parallel Clock Should be Synchronous to Each Other
- I/O Data Valid Capture Window of Six IDELAY Taps
- Running Potential Valid Bits Calculation
- Special Considerations for Timing Constraints

## Parallel Clocks are System Synchronous and the Same Frequency

The parallel clock is the clock domain containing the bus of the signal that will be serialized. This clock must be derived on both FPGAs from the same oscillator. This design does not account for PPM difference from different clock domains. In other words, both FPGAs must be system synchronous. The frequency should also be the same on both FPGAs.

## Serial Clocks are System Synchronous and the Same Frequency

The relationship between the serial clocks on both FPGAs must have similar requirements as the relationship between the parallel clocks. The serial clocks must originate from the same oscillator so there are no PPM differences, and the frequencies must be the same.

## Serial Clock and Parallel Clock Should be Synchronous to Each Other

The relationship between the serial clock and the parallel clock must be synchronous. Use the same MMCM to generate both the clocks. This reduces the uncertainty between the serial clock and the parallel clock and allows for better timing closure.

## I/O Data Valid Capture Window of Six IDELAY Taps

IBIS simulations are required to account for signal integrity. A data valid window of at least six IDELAY taps is required. Refer to the targeted device data sheet to find the delay of one IDELAY tap. For 7 series FPGAs, one IDELAY tap is 78 ps with a 200 MHz reference clock to the IDELAY controller, and 52 ps with a 300 MHz reference clock. If a 78 ps tap is used, a data valid window of  $78\text{ ps} \times 6 = 468\text{ ps}$  is required. The calibration logic calibrates only once during start-up, so a controlled environment is recommended. Remember to include a BUFG duty cycle distortion (DCD) of 200 ps as part of the data valid window. Because the serial clock is running fast, static timing is not required on the I/O. Instead, the calibration logic accounts for finding the center of the eye.

## Running Potential Valid Bits Calculation

Prior to running anything on hardware, you are required to run a calculation of the potential valid bits. This tells you what is possible to transmit in one parallel clock cycle given the serial transmit rate. The details behind the calculation are described in [Steps for Determining Actual MUX Ratio](#).

## Special Considerations for Timing Constraints

### Transmitter

Referring back to [Figure 2](#), the timing constraints from the parallel clock domain into the serial clock domain (and vice versa) are going to be one serial clock cycle. Because the serial clock is operating at a high frequency, it is desirable to relax the timing requirement. This can be done on the transmitter by increasing the SLACK\_CYCLE option in the IP. This allows the ability to multicycle the constraints from the parallel domain into the serial domain of the datapath by the number indicated by the SLACK\_CYCLE parameter. Increasing SLACK\_CYCLE reduces the number of effective valid bits transferred. [Figure 7](#) illustrates how increasing SLACK\_CYCLE relaxes the constraints while reducing the effective valid bits.





Figure 7: SLACK\_CYCLE Enabling Multicycle of Parallel Domain to Serial Domain in Transmitter

### Receiver

Similar to the transmitter, the receiver is able to reduce the timing requirement on the user boundary. This is done by maintaining the same parallel and serial clock frequencies and reducing effective multiplexing ratio. When this is done, the data can be captured faster and is

waiting for the rising edge of the parallel clock for multiple serial clock cycles. The slack cycle in [Figure 8](#) shows how a multicycle constraint can relax this constraint.



*Figure 8: Reducing Valid Bits to Increase Receive Timing Margin*

## Steps for Determining Actual MUX Ratio

Now that the concept of additional timing margin is introduced for both the receiver and transmitter, it is possible to calculate how many actual valid bits are expected for a given board configuration. The actual valid bits per MUX/DeMUX determine how many I/Os are necessary to go between FPGAs. Multiple instances of the MUX/DeMUX result in the total number of signals. The calculations are require the following information:

- Ratio between serial clock and parallel clock domain.
- Board trace delay.
- Package flight times.
- IDELAY delay with zero taps (from timing analyzer). Usually around 1 ns of delay.
- Digital delays from design:
  - Output has two serial clock cycles of latency.
  - Input has four serial clock cycles of latency.
- Desired slack on transmit and receive end.
- Clock skew of the parallel clocks on both FPGAs.

Follow steps 1 through 4 to determine the actual multiplexing ratio with the appropriate slack on the input and output.

### Step 1: Calculate Potential Valid Bits


[Equation 1](#) shows the calculation for the potential (not actual) number of valid bits (PVB):

$$\frac{PCP - IODd - Id - BTd - PFT - PCS}{SBT} = PVB \quad \text{Equation 1}$$

where:

PCP = Parallel clock period  
 IODd = Input and output digital delays  
 Id = IDELAY delay  
 BTd = Board trace delay  
 PFT = Package flight times  
 PCS = Parallel clock skew  
 SBT = Serial bit time  
 PVB = Potential valid bits

The IP customization window also performs the calculation for you within the IP window, as shown in [Figure 9](#). The only limitations are that the IDELAY is fixed at 1 ns, the package flight times are fixed at 200 ps, and the clock skew is assumed to be zero. To work around the limitations, the additional timing can be allocated in the Trace Delay option as shown in [Figure 9](#).



*Figure 9: Potential Valid Bits Calculation within the IP Customization Window*

## Step 2: Decide if the Serial Clock Period is a Timing Bottleneck

Now that the total number of potential valid bits is calculated, it is up to you to decide if a serial clock period is going to be a reasonable timing constraint between the parallel clock and the serial clock. If the serial clock period is reasonable, total potential valid bits can be used as the user data width. If a serial clock period is too tight, it is possible to relax the constraint by proceeding to step 3.

## Step 3: Relaxing Transmitter Constraint

If timing margin is needed at the transmit end, it is possible to relax the timing at the expense of losing a resolution of two valid bits. For example, relaxing the constraint by two extra serial clock cycles results in a loss of four valid bits. Each serial clock cycle of margin loses two valid bits of multiplexing. The timing constraints are already added into the IP, and the RTL is also

modified to allow for the additional time for the parallel data to settle into the serial domain. The SLACK\_CYCLE parameter of the IP needs to be increased to allow for more slack. A SLACK\_CYCLE of one does not increase slack and remains at the serial clock requirement. Increasing SLACK\_CYCLE to one adds one serial clock cycle of slack and consequently loses two valid bits. If the RTL is directly used (instead of the IP), it is necessary to add the appropriate timing exceptions between the serial and parallel clock domain; otherwise, the IP does not function.

## Step 4: Relaxing Receiver Timing

Similar to the transmitter, the receiver timing can also be relaxed at the expense of valid bits. This is also done within the IP with the SLACK\_CYCLE option in the IP, which removes two valid bits for every additional SLACK\_CYCLE. A difference between the transmitter and the receiver design is the effect of the SLACK\_CYCLE option. For the receiver design, the SLACK\_CYCLE option only changes the constraints for the IP and does not affect the source code. In the transmitter, the constraints and source code are affected by the SLACK\_CYCLE option.

### ***Example of Calculating Actual MUX Ratio***

For this example, the parallel clock runs at 25 MHz (40 ns period) and a serial transfer rate of 800 Mb/s (1.25 ns bit time). When the serial transfer rate is 800 Mb/s, the serial clock is 400 MHz (2.5 ns period) because the IDDR or ODDR primitives are used. The IDELAY contributes 1 ns of delay and the package flight times are 125 ps on each end. The board traces are about six inches, yielding about 960 ps of delay. Assume zero skew on the parallel clocks. Using [Equation 1](#) yields 18 potential valid bits, as shown from [Equation 2](#).

$$\frac{40ns - (2+4) \times 2.5ns - 1ns - 0.96ns - 0.250ns - 0ns}{\left(\frac{2.5ns}{2}\right)} = 18 \quad \text{Equation 2}$$

Now it is necessary to determine the number of slack cycles. As of now, there is a 2.5 ns requirement between the parallel clock domain and the serial clock domain. The 2.5 ns requirement is there for the transmitter and the receiver user interface. To increase the slack between the receiver and the transmitter so that the datapath has a 200 MHz requirement (5 ns), you need to add one serial clock cycle on the transmit parameter and remove a clock cycle of valid bits on the receive end. This yields two serial clock cycles being removed, which is four valid bits being removed. In our example above, this yields an effective multiplexing ratio of 14:1 with a 200 MHz boundary timing requirement.

# List of Ports and Parameters

The transmitter parameters and ports are listed in [Table 1](#) and [Table 2](#).

**Table 1: Parameters for the Transmitter Design**

Parameter Name	Type	Description
DATA_WIDTH	Integer	Indicates the number of valid bits you can transmit. This must be a multiple of two.
FULL_WIDTH	Integer	Width of the actual serialization. This is the ratio of between the serial bit time and the parallel period.
SLACK_CYCLE	Integer	The number of additional serial clock cycles of slack between the serial and parallel domains. When using the packaged IP, this adds a multicycle constraint dependent on the number of slack cycles.
DIFFERENTIAL	Boolean	Inserts an IBUFDS when true. When false, a single-ended I/O is assumed.

**Table 2: Ports for the Transmitter Design**

Port Name	Width	Direction	Description
clk_parallel	1	Input	Parallel clock (slow clock).
clk_serial	1	Input	Serial clock (fast clock).
reset	1	Input	Asynchronous reset. Wait until parallel clock and serial clock are stable before deasserting reset.
training_pattern	DATA_WIDTH	Input	Transmits this pattern when stop_training is deasserted. When asserted, real_data is transmitted. It is recommended to make this a static value.
stop_training	1	Input	Transmits training_pattern when deasserted.
real_data	DATA_WIDTH	Input	Data from user logic. Transmitter when stop_training is asserted.
data_out_to_pins	1	Output	Output port driver.
in_training	1	Output	Output status signal indicating when the design is out of training.

The receiver ports and parameters are listed in [Table 3](#) and [Table 4](#).

**Table 3: Parameters for the Receiver Design**

Parameter Name	Type	Description
DATA_WIDTH	Integer	Indicates the number of valid bits you will receive. This must be a multiple of two.
FULL_WIDTH	Integer	Width of the actual serialization. This is the ratio of between the serial bit time and the parallel period.
SLACK_CYCLE	Integer	The number of additional serial clock cycles of slack between the serial and parallel domains. When using the packaged IP, this adds a multicycle constraint dependent on the number of slack cycles.

**Table 3: Parameters for the Receiver Design (Cont'd)**


Parameter Name	Type	Description
DIFFERENTIAL	Boolean	Inserts an IBUFDS when true. When false, a single-ended I/O is assumed.
IODELAY_GRPNAME	String	String labeling the IODELAY_GRPNAME parameter of the IDELAY.

**Table 4: Ports for the Receiver Design**

Port Name	Width	Direction	Description
clk_parallel	1	Input	Parallel clock (slow clock).
clk_serial	1	Input	Serial clock (fast clock).
reset	1	Input	Asynchronous reset. Wait until parallel clock and serial clock are stable before deasserting reset.
training_pattern	DATA_WIDTH	Input	During calibration, this is the pattern used to find a valid pattern. It is recommended to make this a static value.
data_in_from_pins	1	Input	Input port receiver.
real_data_in	DATA_WIDTH	Output	After calibration is complete, this is the data that was received from the transmitter.
calib_comp	1	Output	Indicates that calibration is complete.
delay_locked	1	Output	Indicates the IDELAY CONTROLLER is locked.

# Implementing the Reference Design

The example design includes a simple counter and checker module to validate that the data transmitted and received are equivalent. If they are different, the error flag of the checker asserts and stays asserted until the reset is pulsed. [Figure 10](#) illustrates the connectivity of the design.



*Figure 10: Block Diagram of Example Design*

To implement the example design, a Tcl script labeled `build_project.tcl` is provided in the directory labeled `project`. Launch the Vivado IDE and change the present working directory within the Tcl console to the `project` directory and source the `build_project.tcl` script, as shown in [Figure 11](#).




*Figure 11: Sourcing Tcl Script to Build Project*

After the `build_project.tcl` file is sourced, a project is created and ready to create a bitstream or to run a behavioral simulation.

## Running the Example Design on Hardware

The example design runs on a Kintex®-7 FPGA KC705 evaluation board and requires two pairs of SMA cables to connect the GPIO SMA connectors, as shown in [Figure 12](#).




X1217\_12\_091514

*Figure 12: Hardware Setup*

Within the Vivado IDE, select **Generate Bitstream** within the flow navigator. This generates the bitstream that targets the KC705 board. After the bitstream is generated, program the FPGA within the Vivado hardware manager so that the integrated logic analyzer (ILA) core can be used. The ILA core within the example project only works with Vivado hardware manager, not iMPACT.

Within the hardware manager, run a **Trigger Immediate** to view the data transmitted and received. The data transmitted should be equivalent to the received data. [Figure 13](#) illustrates the ILA data.




*Figure 13: ILA Data*

To purposely invoke an error, disconnect the SMA cables and the error LED lights up. Reconnecting the cable and pulsing reset (GPIO\_SW\_S) turns the error LED (GPIO\_LED\_2\_LS) off.

## Running the Example Simulation


To run the example simulation, select **Run Behavioral Simulation** within the flow navigator of the Vivado IDE, as shown in [Figure 14](#). This launches a behavioral simulation with Vivado simulator.



*Figure 14: Running the Example Behavioral Simulation*

The example simulation test bench connects the transmitter to the receiver and emulates jitter with the assignment to the data\_path\_board\_jitter signal. This allows the calibration state machine to be stressed as it would be on a physical board. Be sure to run the simulation for at least 400  $\mu$ s to ensure that calibration completes.


The wave configuration file is set up to show the signals of the data checker module, as shown in [Figure 15](#).



*Figure 15: Example Waveform after Running Behavioral Simulation*

# How to Include the IP in a Custom Design

The IP blocks provided in this application note are provided in the packaged\_ip directory. To include this IP into a custom design, the packaged IP needs to be included in the IP repository. Go to the Project Settings and select the packaged\_ip directory, as shown in [Figure 16](#). Then click **OK**.



X1217\_16\_091514

**Figure 16: Adding IP to Repository**

After mapping the repository to the packaged IP, the I/O MUX IP appears in the IP catalog, as shown in [Figure 17](#).

IP Catalog					
Name	AXI4	Status	License	VLAN	
BaseIP					
io_mux_in_v1_0		Pre-Produ...	Included	xilinx.com...	
io_mux_out_v1_0		Pre-Produ...	Included	xilinx.com...	

X1217\_17\_091514

**Figure 17: Viewing the IP within the IP Catalog**

# Resource Utilization

[Table 5](#) and [Table 6](#) provide a reference for the size of the transmitter and receiver with a FULL\_WIDTH parameter set to 32. The designs were intended to be as lightweight as possible.

*Table 5: Transmitter Utilization*


Data Width	LUTs	Flip-Flops
16	18	19
20	22	23
24	26	27

*Table 6: Receiver Utilization*

Valid Bits	LUTs	Flip-Flops
16	60	80
20	63	92
24	65	104

# File Structure

[Figure 18](#) shows the directory structure of the reference design:



X1217\_18\_091614

*Figure 18: Design File Hierarchy*

# Table of Definitions

[Table 7](#) defines some of the terms used in this application note.

*Table 7: Table of Definitions*

Term	Definition
Valid bits	The bits you are able to transmit and receive.
Potential valid bits	The number of potential bits without relating the constraints at the user logic boundaries.
Clipping bits	The bits that are sent after the valid bits and are disregarded.
Parallel clock	The user clock domain. This is generally a slow clock rate for emulation systems.
Serial clock	The transmit and receive clock. This clock is faster than the parallel clock.
Effective MUX ratio	This is the ratio of multiplexing to the user. The clipped bits are not included.
Actual MUX ratio	This is the ratio between the parallel clock and the serial clock.

---

## Conclusion

FPGAs are commonly used to emulate complex ASIC designs that span several of the largest FPGAs. Sometimes, thousands of signals need to go between FPGAs. This application note provides the ASIC designer a method of multiplexing I/Os without introducing any cycles of latency.

---

## Reference Design

You can download the [Reference Design Files](#) for this application note from the Xilinx website.

[Table 8](#) shows the reference design matrix.

*Table 8: Reference Design Matrix*

Parameter	Description
<b>General</b>	
Developer name	Luis Bielich
Target devices	Kintex-7 FPGAs
Source code provided?	Yes
Source code format (if provided)	RTL, Tcl
<b>Simulation</b>	
Functional simulation performed?	Yes
Timing simulation performed?	Yes
Test bench provided for functional and timing simulation?	Both

**Table 8: Reference Design Matrix (Cont'd)**

Parameter	Description
Test bench format	Verilog/SystemVerilog
Simulator software and version	Vivado simulator
SPICE/IBIS simulations	N/A
Implementation software tool(s) and version	2014.4
Static timing analysis performed?	Yes
<b>Hardware Verification</b>	
Hardware verified?	Yes
Platform used for verification	KC705 board

## Revision History

The following table shows the revision history for this document.

Date	Version	Revision
03/17/2015	1.0	Initial Xilinx release.

## Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>.

### Automotive Applications Disclaimer

XILINX PRODUCTS ARE NOT DESIGNED OR INTENDED TO BE FAIL-SAFE, OR FOR USE IN ANY APPLICATION REQUIRING FAIL-SAFE PERFORMANCE, SUCH AS APPLICATIONS RELATED TO: (I) THE DEPLOYMENT OF AIRBAGS, (II) CONTROL OF A VEHICLE, UNLESS THERE IS A FAIL-SAFE OR REDUNDANCY FEATURE (WHICH DOES NOT INCLUDE USE OF SOFTWARE IN THE XILINX DEVICE TO IMPLEMENT THE REDUNDANCY) AND A WARNING SIGNAL UPON FAILURE TO THE OPERATOR, OR (III) USES THAT COULD LEAD TO DEATH OR PERSONAL INJURY. CUSTOMER ASSUMES THE SOLE RISK AND LIABILITY OF ANY USE OF XILINX PRODUCTS IN SUCH APPLICATIONS.

© Copyright 2015 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.